

TIREFLIP 180® FOOT REPLACEMENT INSTRUCTIONS

Kit Includes:

- 1 - Foot
- 1 - Top Plate
- 1 - Locking Nut
- 2 - Rubber Washers

Tools Needed:

- Adjustable Crescent Wrench (or Metric 16 Wrench)
- M6 Metric Allen Wrench

DIRECTIONS



1. Remove rubber cover from the old foot and install on new foot.



2. Install the first rubber washer - flat side UP on the base of the foot.

Call for details: **1-866-219-5335** Outside the US: **1-908-879-2713**

www.TheAbsCompany.com

The Abs Company, 8429 Lorraine Rd #362, Lakewood Ranch, FL 34202

TIREFLIP 180® FOOT REPLACEMENT INSTRUCTIONS



We Change Lives from the Core®

DIRECTIONS



3. Insert new foot through the frame of the TireFlip and put rubber washer on top flat side DOWN. (photo does not show TireFlip frame)



4. Replace top plate with new one. Twist to screw in the new plate.

Call for details: **1-866-219-5335** Outside the US: **1-908-879-2713**

www.TheAbsCompany.com

The Abs Company, 8429 Lorraine Rd #362, Lakewood Ranch, FL 34202

TIREFLIP 180® FOOT REPLACEMENT INSTRUCTIONS



We Change Lives from the Core®



5. Install M16 nut on top of upper plate and secure with an Adjustable Crescent Wrench or metric 16 wrench. This will prevent bumper from getting loose in the future.



6. Re-attach bumper with M6 bolts using an M6 Metric Allen Wrench.

Older style TireFlips will have 6-M6 bolts while newer styles with the ring will only 3-M6 bolts.

Call for details: **1-866-219-5335** Outside the US: **1-908-879-2713**

www.TheAbsCompany.com

The Abs Company, 8429 Lorraine Rd #362, Lakewood Ranch, FL 34202